

Lomanco® Omni Solar Vent™ (OSV-40)

Dome Replacement Instructions

Tools Required:

3/8" Wrench

Working from the inside of your attic or air space:

1. Disable the motor. Disconnect the motor from the power wires coming from the solar panel.

On your roof:

- 2. Remove the old dome. Using the 3/8" wrench, remove the 4 lock nuts securing the old dome to the base flashing. Lift and remove the old dome from the base.
- 3. Install the new dome. Align the holes in the new dome with the mounting studs on the base flashing and set the new dome in place, being careful not to damage the screen. Secure the dome with the 4 lock nuts, using the 3/8" wrench to tighten them until snug.

Inside your attic:

4. Reconnect the motor. Connect the red solar panel wire to the red motor wire, and then connect the black solar panel wire to the black motor wire.

WARNING: The unit will begin operation once the connection is made.



