

EXHAUST VENTS allow **HEAT** and **MOISTURE** out of your attic area. INTAKE VENTS allow fresh air into your attic area.

one without the other

does not work!

Each must be of proper type, size and number for your home.

Only a balanced ventilation system (50% Exhaust & 50% Intake) gives you proper protection against **HEAT** and **MOISTURE**.

Copyright 2017 • Lomanco, Inc. 2101 West Main • Jacksonville, AR 72076 • 1.800.643.5596

LOMANCO VENTILATION PRODUCTS PUT HEAT & MOISTURE ON THE RUN!

3 MUST DO STEPS TO ATTIC VENTILATION

INSTALL ALL EXHAUST VENTILATION AT THE SAME HEIGHT WITHIN A COMMON ATTIC AREA.

Installation of exhaust vents at more than one level on a roof allows the upper exhaust vent to pull air in from lower exhaust vents rather than from the intake vents. Intake air must come from intake vents located near the lower part of the attic space to properly ventilate the total attic area and eliminate weather infiltration.

INSTALL ONLY ONE TYPE OF EXHAUST VENTILATION WITHIN A COMMON ATTIC AREA.

Exhaust vents pull air from the easiest intake source. Vent types cannot be mixed. The use of different types of exhaust vents could make one of the vents act as intake for the other. Intake air must come from intake vents located near the lower part of the attic space to properly ventilate the total attic area and eliminate weather infiltration.

50% EXHAUST VENTILATION - Use a Lomanco Ventilation Selector Guide, the calculators at Iomanco.com or the Lomanco Vent Selector App to determine the number of vents needed to properly ventilate an attic to meet the minimum code ventilation standard.

50% INTAKE VENTILATION - Intake vents located near the lower part of the attic area are required to balance out your ventilation system.


BUILD YOUR VENTILATION SYSTEMS

STATIC VELTS ARE DESIGNED TO TAKE MAXIMUM ADVANTAGE OF THE NATURAL MOVEMENT OF HEAT AND AIR.


















100% GUARANTEED for as long as you own them!





IS ONDER



HEAT & MOUSTURE THEY <u>NEVER</u> STOP TRYING TO TAKE OVER YOUR ATTIC! BAROMETER

If **HEAT** and **MOISTURE** are not removed from your home by proper ventilation - serious damage can occur- plus higher utility bills!

HEAT travels down to your living space.

When **HEAT** is trapped in your attic so is

MOISTURE creeps into your attic and gets trapped - then you're in for trouble.

Don't forget your crawlspace. MOISTURE crawls up from under your house too!

SOME COSTLY PROBLEMS HEAT AND MOISTURE CAN CAUSE...




Wet insulation means trapped MOISTURE that will slowly degrade the entire roofing system, from the decking to the building itself!




Trapped MOISTURE works down through walls and causes paint to bubble, crack and peel!




HEAT & MOISTURE steal years of useful life from the roof over your head!




Without proper ventilation, the crawlspace under your home collects MOISTURE that promotes mildew, mold and rot!



Trapped MOISTURE can even cause serious damage to your home!



Trapped **HEAT** causes your air conditioning system to work itself to death - prematurely! And it eats you alive with higher utility bills!



ALL major shingle manufacturers void their warranties if their shingles are installed over improperly ventilated attics.